


## CIRCUIT DIAGRAM



Uses Burgess XX30E and 8R batteries



Special suspenders (shown at right) are also available for men who prefer to wear battery case and amplifier in a compact unit under the shirt. This arrangement simplifies wearing and conceals all but a few inches of cord from collar to receiver.

## Easy for men to wear . . .

Men wear the amplifier unit and battery case in shirt, coat or vest pockets (shown at left) or wear the battery case separately in hip pocket or in a handy pouch on the belt.



## Carrying batteries . . .

Women may wear both amplifier and battery case in one compact unit, concealed below the neckline of the dress (Figure A) or may wear battery case separately in tiny pouch pinned to brassiere or girdle (Figure B). Although these are the most popular arrangements, your Western Electric Hearing Aid Dealer can suggest other wearing methods which you may find more





FIG. A

convenient. Most dresses will cover your hearing aid amplifier unit and battery case successfully, but it is wise to consider your hearing aid when buying clothes. A soft fullness at the bosom of any dress will best conceal the amplifier unit, which is clipped to your brassiere or slip. Avoid heavy layers of fabric which muffle sound or which cause "rubbing noises."